

PLASTİK FİLTRELER

PLASTIC FILTERS

DİKKAT EDİLMESİ GEREKEN HUSUSLAR

- ✚ Elek ve disk Filtrede bağlantı yönüne dikkat edilmelidir.
- ✚ Sistem çalıştırılmadan önce filtrenin temiz olup olmadığı kontrol edilmelidir.
- ✚ Filtre giriş ile çıkış basınçları arasında fark 1 bar dan fazla görüldüğünde Filtre temizlenmelidir.
- ✚ Sistemin sağlıklı çalışması için filtreler düzenli temizlenmelidir.
- ✚ Tahliye vana montajı için filtre kapak üzerinde bulunan kör tapa çıkartılır ve bir matkap yardımı ile delinerek 3/4" dişi vana montajı yapılır.

POINTS TO TAKE INTO CONSIDERATION

- ✚ In the sieve and disc filter, attention should be paid to the connection direction.
- ✚ Before the system is started, it should be checked whether the filter is clean.
- ✚ When the difference between the filter inlet and outlet pressures is more than 1 bar, the filter should be cleaned.
- ✚ In order for the system to work properly, the filters must be cleaned regularly.
- ✚ For the installation of the discharge valve, the blind plug on the filter cover is removed and a 3/4" female valve is mounted by drilling it with the help of a drill.